

While our Yaxle Rod dress up kits were originally designed for M8 Softails fitted with Inverted Forks, They can easily be fitted to CVO touring models (with inverted forks) by simply trimming the right side axle boss flush. Simply remove the axle, trim the end cap off with a lathe. (A cutoff wheel, grinder, hack saw, can also be used)

Reinstall the modified Axle, torque it and pinch bolt. Use the blue loctite provided. Then install the Yaxle Rod through the hollow Axle, Center the rod and install end caps using blue Loctite provided and snug tight to 10 ft lbs. (use allen tools that are in excellent condition to avoid scratching anodized surfaces)

See pictures for visual reference.





